



CLEANING INSTRUCTIONS FOR 304 STAINLESS STEEL ELEVATOR FIXTURES

Elevator components may contain polycarbonate material and
Painted surfaces.

WARNING

Do Not Use

Cleaning agents which contain ketones, benzene, methanol,
toluene or alkaline or ammonia-based cleaning agents.

Recommended Cleaning Instructions:

1. Use a PH-neutral or slightly acidic cleaning product with ethylic alcohol, isopropyl alcohol or ethylene glycol.
2. Acceptable cleaners include Formula 409, Windex or Twinkle stainless steel polish.
3. Do not use dry cotton cloths or sponges.
4. Do not leave cleaning agents on the panel for long periods. Remove with a wet cotton cloth and warm water.